

PRODUCT DATA SHEET

Sika Boom[®] Cleaner

PU foam cleaner for Sika Boom[®] application guns and foam residues

DESCRIPTION

Sika Boom[®] Cleaner is suitable for cleaning Sika Boom[®] application guns and fresh PU foam residues from tools and surfaces.

USES

- Flushing the inside of the Sika Boom[®] application guns after use
- Removing fresh, uncured PU foam residues from tools and other surfaces
- Cleaning and removing grease from contaminated substrates

CHARACTERISTICS / ADVANTAGES

- Dissolves uncured PU foam effectively
- Easy and quick flushing of the application gun
- Attached nozzle for precise manual application

PRODUCT INFORMATION

Composition	Solvent-based cleaning agent
Packaging	500 ml pressurised canister with rubber valve, 12 canisters per box
Colour	Transparent
Shelf life	24 months
Storage conditions	The Product must be stored in original, unopened and undamaged sealed packaging in dry conditions at temperatures between +5 °C and +25 °C. Store in an upright position. Protect the canister from direct sunlight and temperatures above +50 °C (danger of exploding). Always refer to packaging.
Density	~0,70 kg/l

APPLICATION INFORMATION

Ambient air temperature	Min. +5 °C - max. +35 °C
--------------------------------	--------------------------

BASIS OF PRODUCT DATA

All technical data stated in this Product Data Sheet are based on laboratory tests. Actual measured data may vary due to circumstances beyond our control.

ECOLOGY, HEALTH AND SAFETY

For information and advice on the safe handling, storage and disposal of chemical products, users shall refer to the most recent Safety Data Sheet (SDS) containing physical, ecological, toxicological and other safety-related data.

APPLICATION INSTRUCTIONS

APPLICATION METHOD / TOOLS

IMPORTANT

Clean immediately

Clean all tools and substrates immediately after the application. Cured material can only be removed mechanically.

IMPORTANT

Potential discolouration

The Product can partly dissolve or discolour sensitive substrates (e.g. varnish, paint, plastics, textiles). We recommend testing the compatibility and colour fastness discretely on an unobtrusive small area before use.

IMPORTANT

Canister orientation

To ensure proper flow, hold the canister upside down while dispensing.

IMPORTANT

Do not open the product using excessive force.

IMPORTANT

The cleaner discharges with high pressure.

CLEANING BY NOZZLE

The Product with the attached nozzle can be used to clean the outside of the application gun or to remove residues from tools and substrates.

1. Mount the attached nozzle on top of the valve of the Product.
2. Spray the Product directly onto the fresh foam by pressing the nozzle and allow it to react for 5–10 seconds.
3. Wipe-off the residue with a clean cloth.

Sika Danmark A/S

Hirsemarken 5

3520 Farum

Tlf. +45 48 18 85 85

www.sika.dk



PRODUCT DATA SHEET

Sika Boom® Cleaner

July 2021, Version 03.01

02051602000000015

FLUSHING THE APPLICATION GUN

The Product without the attached nozzle can be used to flush the application gun.

1. Screw the canister onto the application gun immediately after removing the foam canister.
2. Press the trigger of the application gun a few times to flush out all uncured foam residue.
3. Wait 2 minutes and repeat pressing the trigger until clean liquid comes out of the application gun.
4. After cleaning, remove the canister from the application gun and release all remaining Product inside the application gun

LOCAL RESTRICTIONS

Please note that as a result of specific local regulations the declared data for this product may vary from country to country. Please consult the local Product Data Sheet for the exact product data.

LEGAL NOTES

Any information or suggestions for use concerning Sika's products, which we either in writing or orally have given buyers or end-users of the product, have been given in good faith based on our own experiences and based on approved praxis and the technological and scientific knowledge on the time of giving such suggestions and information, which are given without any type of guarantees, and which do not lead to any further responsibility from Sika Danmark A/S, besides what is stated in the sales agreement in question. The buyer or end-user should themselves investigate or otherwise make sure, that our products are suitable for the use in question and further make sure that the products are kept and used correct and in agreement with the published rules and considering the actual conditions in order to avoid damages or less satisfactory results. Any order is accepted and any deliverance is affected according to the general terms of sales and delivery from Sika Danmark A/S, which are considered known and accepted, and which could be handed out when asked for. Our catalogues are not up-dated automatically. The present product data sheet is only for use in Denmark. Values stated in the present product data sheet should be seen as recommended, unless stated otherwise.

SikaBoomCleaner-en-DK-(07-2021)-3-1.pdf