

PRODUCT DATA SHEET

Sika® Wonder Wipes

MULTI-USE CLEANING WIPES FOR THE BUILDING TRADE

DESCRIPTION

Sika® Wonder Wipes are specially formulated to clean hands, tools and surfaces from wet and semi-cured paint, sealant, adhesive, bitumen, expanding foam, oil, grease and even silicone. Particularly useful when there is no water on site. Our new Sika® Wonder Wipes Biodegradable are extra thick, strong and 100 % biodegradable that are tough on grime and specially formulated for the trade.

USES

Cleaning wet and semi-cured paints, sealants, adhesives, bitumen, polyurethanes, expanding foams, polyester fillers and epoxies from hands, tools and surfaces.

FEATURES

- Cleans hands, tools and surfaces.
- Formulated to remove the toughest of grime.
- Contains an anti-bacterial additive.
- Contains aloe vera to condition skin and prevent dryness and cracking.

CERTIFICATES AND TEST REPORTS

Sika® Wonder Wipes and Sika® Wonder Wipes Biodegradable contain an anti-bacterial additive tested by an independent laboratory to EN 1276 chemical disinfectants and antiseptics.

Sika® Wonder Wipes Biodegradable are made with 100 % plant based biodegradable fibres that conform to EN 13432 in water.

PRODUCT INFORMATION

| | | |
|--------------------|---|-------------------------------------|
| Packaging | Availability | |
| | Heavy Duty version | 60 wipes |
| | Wonder Wipes version | 100 wipes 300 wipes 500 wipes |
| | Spray version | 1 liter |
| Shelf life | Sika® Wonder Wipes Heavy Duty must be used within 24 months from the date of manufacture and within 6 months from opening. Sika® Wonder Wipes must be used within 36 months from the date of manufacture and within 6 months from opening. Sika® Wonder Wipes Spray must be used within 24 months from the date of manufacture. | |
| Storage conditions | Store in cool dry conditions away from direct sunlight between +5 °C and +25 °C. Storage outside these parameters will significantly reduce shelf life. | |

BASIS OF PRODUCT DATA

based on laboratory tests. Actual measured data may vary due to circumstances beyond our control.

All technical data stated in this Product Data Sheet are

LIMITATIONS OF USE

- Do not use on porous surfaces such as untreated wood.
- Use only as directed.
- Store only in original container.
- As with all detergents / products containing detergents, people with sensitive or damaged skin should avoid prolonged contact with skin.
- It is the users responsibility to determine suitability for use. Make test and in doubt, contact our Technical Services department for advice.

ECOLOGY, HEALTH AND SAFETY

Sika® Wonder Wipes and Sika® Wonder Wipes Heavy Duty is covered by the Cosmetics legislation: Special documents can be handed over on request.

Sika® Wonder Wipes Spray is covered by this: For information and advice on the safe handling, storage and disposal of chemical products, users shall refer to the most recent Safety Data Sheet (SDS) containing physical, ecological, toxicological and other safety-related data.

APPLICATION INSTRUCTIONS

APPLICATION METHOD / TOOLS

Tub

Pull off lid and open closure. Find start wipe in centre of roll. Pull out approx 1 foot of wipes and thread through lid. Replace lid immediately and reseal closure.

Flow-pack

Open the plastic lid on top of the flow pack and peel back the inner seal. Pull through the required amount of wipes and then ensure to close the lid to prevent the wipes from drying out. When using on spills, use immediately for the best results.

Spray

Always test a small inconspicuous area prior to full application. Remove the CRC cap and attach the spray head provided. Spray onto the area that requires cleaning and wipe with our Paper Wipe Roll or similar. To extend the life of Sika® Wonder Wipes add some of the spray liquid to the tub, or add directly to a wipe. When using on spills, use immediately for best results.

LOCAL RESTRICTIONS

Please note that as a result of specific local regulations the declared data for this product may vary from country to country. Please consult the local Product Data Sheet for the exact product data.

LEGAL NOTES

Any information or suggestions for use concerning Sika's products, which we either in writing or orally have given buyers or end-users of the product, have been given in good faith based on our own experiences and based on approved praxis and the technological and scientific knowledge on the time of giving such suggestions and information, which are given without any type of guarantees, and which do not lead to any further responsibility from Sika Danmark A/S, besides what is stated in the sales agreement in question. The buyer or end-user should themselves investigate or otherwise make sure, that our products are suitable for the use in question and further make sure that the products are kept and used correct and in agreement with the published rules and considering the actual conditions in order to avoid damages or less satisfactory results. Any order is accepted and any deliverance is affected according to the general terms of sales and delivery from Sika Danmark A/S, which are considered known and accepted, and which could be handed out when asked for. Our catalogues are not up-dated automatically. The present product data sheet is only for use in Denmark. Values stated in the present product data sheet should be seen as recommended, unless stated otherwise.

Sika Danmark A/S

Hirsemarken 5
3520 Farum
Tlf. +45 48 18 85 85
www.sika.dk



PRODUCT DATA SHEET

Sika® Wonder Wipes
January 2026, Version 01.01
020516020000000082

SikaWonderWipes-en-DK-(01-2026)-1-1.pdf

