

INDUSTRIAL BIOTECHNOLOGY RESEARCH CENTRE Building 19, SIRIM Complex

1, Persiaran Dato' Menteri, Section 2, P. O. Box 7035 40700 Shah Alam, Selangor Darul Ehsan, MALAYSIA Tel: 603 - 5544 6953 / 6960 Fax: 603 - 5544 6988

Website: www.sirim.my

TEST REPORT

REPORT NO: R0826/21/B19/01 - A1

PAGE: 1 of 4

This report is NOT a Quality Assurance Certificate NOR an Approval Permit. This report refers only to samples submitted by the customer to SIRIM Berhad and tested by SIRIM Berhad. This report shall not be reproduced, except in full and shall not be used for advertising purposes by any means or forms without written approval from President & Chief Executive of SIRIM Berhad.

Job No.

: J0826/21

Applicant

: SIRIM QAS International Sdn. Bhd.

Chemical and Consumer Section, Building 16,

SIRIM Berhad.

Manufacturer / Company

: SIKA Services AG

Sample/Trade Name

Sikaflex®PRO-3 Purform

Reference Standard / Method of Test : 1. BS 6920-1:2014. Suitability of non-metallic products for use in contact with water intended for human consumption with regard to their effect on the quality of the water.- Part 1: Specification (LWI-238-01)

(2111 200 01)

 BS 6920-2.1:2014. Suitability of non-metallic materials and products for use in contact with water intended for human consumption with regard to their effect on the quality of the water - Part 2: Methods of test - Section 2.1: Samples for testing. (LWI-238-01)

 BS 6920-2.5:2000+A2:2014. Suitability of non-metallic products for use in contact with water intended for human consumption with regard to their effect on the quality of the water - Part 2: Methods of test - Section 2.5: The extraction of substances that

may be of concern to public health (LWI-238-01)

Description of Sample

: Received one sample consisting of four sample pieces in good condition for testing with the following identification:

- Model/Brand/Marking: Not provided
- 2. Reference No: J20211400942
- 3. Designation: Not provided
- 4. Date of Manufacture: Not provided
- 5. Nature of Material: Not provided
- 6. Storage Condition: Room temperature
- 7. Colour: Grey
- 8. Shape/Form: Cylinder
- 9. Dimension: Approximately height 52 mm, diameter 12 mm
- 10. Appearance: Solid smooth surface
- 11. Opacity: Opaque

Date Received

: 27 July 2021

Issue Date

: 11 November 2021

Note: This Test Report supersedes the previous Test Report no. R0826/21/B19/01 dated 12 August 2021 which has been withdrawn and therefore not valid.





TEST REPORT

REPORT NO: R0826/21/B19/01 - A1

PAGE: 2 of 4

This report is NOT a Quality Assurance Certificate NOR an Approval Permit. This report refers only to samples submitted by the customer to SIRIM Berhad and tested by SIRIM Berhad. This report shall not be reproduced, except in full and shall not be used for advertising purposes by any means or forms without written approval from President & Chief Executive of SIRIM Berhad.

APPROVED SIGNATORIES

We, the undersigned, declare that the methods, results and data contained in this report faithfully reflect the procedures used and raw data collected throughout the testing.

(SUZAINI BADRUDIN)

Reviewer

Industrial Biotechnology Research Centre

SIRIM Berhad

1 1 NOV 2021

Date

(NOOR RABIHAH AID)

Analyst

Industrial Biotechnology Research Centre

SIRIM Berhad

1 1 NOV 2021

Date





TEST REPORT

REPORT NO: R0826/21/B19/01 - A1

PAGE: 3 of 4

This report is NOT a Quality Assurance Certificate NOR an Approval Permit. This report refers only to samples submitted by the customer to SIRIM Berhad and tested by SIRIM Berhad. This report shall not be reproduced, except in full and shall not be used for advertising purposes by any means or forms without written approval from President & Chief Executive of SIRIM Berhad.

1.0 **Test timetable**

Receipt of sample:

27 July 2021

Maintenance of cell culture: 20 July 2021-27 July 2021

Extraction procedure:

02 August 2021-03 August 2021

Preparation of cells:

03 August 2021

Growth procedure:

03 August 2021- 04 August 2021

End of test:

04 August 2021

2.0 **Test method**

2.1 Test summary

A screening procedure (simple cytotoxicity test) to test leachates from the Sikaflex®PRO-3 Purform biologically active compound was carried out according to BS 6920. Leachates from the sample after a 24-hour extraction at (23±2) °C was used to prepare growth medium. The morphology of a mammalian cell line following a 24-hour culture in the growth medium was observed. NO OTHER TESTS WERE UNDERTAKEN ON THIS PRODUCT.

Significance and rationale 2.2

This method is only an initial screening test for substances potentially hazardous to health and suitable for all non-metallic materials that may be used in contact with water intended for human consumption. A satisfactory result indicates that the leachate probably does not contain significant amounts of acutely toxic substances, but it does not indicate the absence of small quantities of substances, which may be harmful on prolonged exposure.

Cell culture 2.3

American Type Culture Collection CCL-1, NCTC clone 929 Areolar Fibroblast Mouse.

2.4 Test procedure

The procedure was divided into three stages as follows.

2.4.1 Cell culture maintenance

Cells were grown in tissue culture grade flasks and routinely examined to ensure they remain healthy.

2.4.2 Sample extraction and preparation of growth media

The sample pieces were extracted in 500 mL of reverse osmosis water at (23±2) °C for 24 hours. A validation solution (800 mg/L zinc sulfate) and a blank were included in the test. Portions of the sample extracts, validation solution and blank were used to dilute the concentrated growth medium. Freshly trypsinized cells was added to each preparation and transferred into a 24-well tissue culture plate. The extracts were assessed in replicates of three. The plate was incubated at (37±1) °C in a humidified atmosphere of 5 % carbon dioxide and 95 % air for 24 hours.

2.4.3 Effect on cell culture

The condition of cells in each well was examined microscopically. The presence or absence of a confluent cell layer, the presence of any irregular shaped cell or cells showing signs or 'rounding off', and the appearance of any cells floating in the growth medium was recorded.







TEST REPORT

REPORT NO: R0826/21/B19/01 – A1 PAGE: 4 of 4

This report is NOT a Quality Assurance Certificate NOR an Approval Permit. This report refers only to samples submitted by the customer to SIRIM Berhad and tested by SIRIM Berhad. This report shall not be reproduced, except in full and shall not be used for advertising purposes by any means or forms without written approval from President & Chief Executive of SIRIM Berhad.

3.0 Results

The table below shows cytotoxicity effects Sikaflex®PRO-3 Purform

		10 CONTO. 18 VAN. 1940
	Replicates	Effects on cell culture
Extract of Sample group	Α	Healthy confluent monolayer
	В	Healthy confluent monolayer
	С	Healthy confluent monolayer
Validation solution	Α	Cells 'rounding off' and floating. No monolayer
	В	Cells 'rounding off' and floating. No monolayer
	С	Cells 'rounding off' and floating. No monolayer
Blank	Α	Healthy confluent monolayer
	В	Healthy confluent monolayer
	С	Healthy confluent monolayer

4.0 Analysis and interpretation

Cell cultures in the extract of sample group showed healthy confluent monolayer, comparable to the blank, which indicate a non-cytotoxic response. Monolayer of cell culture was not present in the validation solution. The cells showed severe 'rounding off' and floating in the validation solution preparation, which indicate a cytotoxic response.

5.0 Conclusion

The sample **Sikaflex®PRO-3 Purform** exhibited no cytotoxicity response under the conditions of this test. On the basis of these results, the sample tested complied with all the requirements of BS 6920: Part 1:2014, Clause 7.







THE CONDITIONS RELATING TO THE USE OF THE INDUSTRIAL BIOTECHNOLOGY RESEARCH CENTRE TEST REPORT

- A Test Report will be issued in respect of Testing Services conducted and shall related only to the sample actually tested. SIRIM
 Berhad makes no warranty whatsoever and the Applicant shall not represent in any manner that any duplication or mass
 production of the Product is same as the Sample actually tested or that SIRIM Berhad has tested any of the duplicated or mass
 produced Product.
- 2. The Test Report shall not be amended, changed, varied or modified in any manner whatsoever by the Applicant or otherwise.
- 3. If the Test Report is to be furnished to any third party or to the public, each such Test Report shall be furnished in full, legible and in its entirety.
- 4. The Test Report shall not be reproduced and shall not in any event be used for any advertising purposes or whatsoever without written approval from the President & Chief Executive of SIRIM Berhad of No. 1, Persiaran Dato' Menteri, Building 5, Section 2, P. O. Box 7035, 40700 Shah Alam, Selangor Darul Ehsan.
- 5. Customer (Applicant/Manufacturer/Factory, etc.) is not permitted to use any SIRIM Berhad, other SIRIM Berhad's subsidiaries logo on packaging, sample's manual, technical specification, brochures/flyers or any other means.
- 6. If such approval is obtained from the President & Chief Executive, the Applicant may only include the phrase, "A sample of this product has been tested by SIRIM Berhad ... (Test Report No) ... (dated) ... (for what test) ... (to which standard)"or such similar words which stress that only the Sample was actually tested. This phrase shall only be used for the purpose of product advertisement or product promotion (eg; brochures). For avoidance of doubt, the statement shall not be used on the sample and packaging of the sample.
- 7. In the event there is an investigation from a Government Regulatory Agency concerning the applicant's Test Report, SIRIM Berhad may disclose the information pertaining to the Test Report for purposes of such investigation.
- 8. Further or in the alternative, it is strictly forbidden to represent in any manner whatsoever that SIRIM Berhad and/or other SIRIM's subsidiaries has endorsed, approved or validated the Product of the Applicant in any manner whatsoever.
- 9. In the event the applicant is found in breach of this provision, SIRIM Berhad and/or other SIRIM's subsidiaries without prejudice to any other rights and remedies may take whatever action necessary including but not limited to:
 - a) Informing and placing a notice in the media;
 - b) Obtaining an injunction from Court (cost on a solicitor-client basis to be borne by the Applicant);
 - c) Refusing to accept any further Product for Testing Services from the Applicant or whatsoever related to the Applicant, whether subsidiary or otherwise;
 - d) Instructing the Applicant to withdraw and recall the advertisement, statement or document in question and advertise a clarification and apology to SIRIM Berhad and/or other SIRIM's subsidiaries twice in a national publication of SIRIM Berhad's choice at the Applicant's sole cost; and
 - e) Informing or lodging a report pertaining the Applicant's Test Report with the relevant authorities.
- 10. Certified true copies of the Test Report may be issued upon request by the applicant upon payment of the relevant fee.
- 11. Corrections to test report shall only be allowed within 6 months from issuance date of the Test Report of the relevant fee and shall be limited to maximum 3 times, after either case whichever occurs earlier, a new Test Report shall be issued and replace the previous one (having error(s) or lack of information) with relevant fee. Issuance of Supplementary Report to the original Test Report shall be for the followings:
 - a) Misprints and typo errors;
 - b) Missing technical information;
 - c) Test data not reported;
 - d) Mistake in reporting of test data.
- 12. Any amendment requested from customers on the test report issued shall be in writing.
- 13. SIRIM reserves the right in its sole discretion to terminate or modify this permission.