

PRODUCT DATA SHEET

Sika® Reemat Lite

GLASS FIBRE MAT REINFORCEMENT

DESCRIPTION

Sika® Reemat Lite is a glass fibre mat reinforcement for Sikagard® Hygienic Coating systems

USES

- Reinforcement for Sikagard® Hygienic Coating Systems
- Reinforcement for Sikagard® Hygienic Coating detailing
- For new construction and refurbishment projects

CHARACTERISTICS / ADVANTAGES

- Easy and quick application
- Easy to adjust to complicated details
- Ensures the correct thickness of the base coat
- Enhance the crack-bridging properties of the system
- Enhance mechanical properties of the system

PRODUCT INFORMATION

Composition	Random glass fibre matting
Packaging	Rolls: 1m wide by 50m long
Appearance / Colour	White
Shelf life	Product does not expire if correctly stored
Storage conditions	The product must be stored properly in original, unopened and undamaged sealed packaging, flat and wrinkle free, in dry conditions at temperatures between +5 °C and +35 °C.
Density	~30 g / m ²

SYSTEMS

Systems	For detailed information regarding system build-ups, please refer to the System or Product Data Sheet of the relevant Sikagard® Hygienic Coating System.
----------------	--

APPLICATION INSTRUCTIONS

APPLICATION

Prior the application of the Sikagard® Hygienic Coating System the priming coat if used must have cured for the appropriate Waiting Time / Overcoating (please refer to the PDS of the appropriate primer). Damageable areas (handrails etc.) have to be protected with tape or plastic wrapping.

Sika® Reemat Lite is applied in combination with Sikagard® Hygienic Coatings.
Apply first coat of Sikagard® Hygienic Coating with a consumption rate according to the PDS of the relevant hygienic coating system. Work only so far in advance that the material stays liquid.
Roll out the Sika® Reemat Lite and ensure that there are no bubbles or creases. Overlapping of Sika® Reemat Lite must be minimum 5 cm and ensure overlaps are sufficiently wet to bond.
The roller may require only a little extra material to remain wet but no further significant material needs to be added at this stage.
After the coat as had the appropriate Waiting Time / Overcoating continue with subsequent coats as per the relevant Sikagard® Hygienic Coating Datasheet / System Datasheet.

IMPORTANT CONSIDERATIONS

Limitations will be dictated by the individual Sikagard® Hygienic Coating being used – Please consult relevant Product Datasheet / System Datasheet.

BASIS OF PRODUCT DATA

All technical data stated in this Product Data Sheet are based on laboratory tests. Actual measured data may vary due to circumstances beyond our control.

LOCAL RESTRICTIONS

Please note that as a result of specific local regulations the declared data for this product may vary from country to country. Please consult the local Product Data Sheet for the exact product data.

ECOLOGY, HEALTH AND SAFETY

REGULATION (EC) NO 1907/2006 - REACH

LEGAL NOTES

Any information or suggestions for use concerning Sika's products, which we either in writing or orally have given buyers or end-users of the product, have been given in good faith based on our own experiences and based on approved praxis and the technological and scientific knowledge on the time of giving such suggestions and information, which are given without any type of guarantees, and which do not lead to any further responsibility from Sika Danmark A/S, besides what is stated in the sales agreement in question. The buyer or end-user should themselves investigate or otherwise make sure, that our products are suitable for the use in question and further make sure that the products are kept and used correct and in agreement with the published rules and considering the actual conditions in order to avoid damages or less satisfactory results. Any order is accepted and any deliverance is affected according to the general terms of sales and delivery from Sika Danmark A/S, which are considered known and accepted, and which could be handed out when asked for. Our catalogues are not up-dated automatically. The present product data sheet is only for use in Denmark. Values stated in the present product data sheet should be seen as recommended, unless stated otherwise.

Sika Danmark A/S
Hirsemarken 5
3520 Farum
Tlf. +45 48 18 85 85
www.sika.dk



PRODUCT DATA SHEET
Sika® Reemat Lite
May 2020, Version 03.01
020816110010000009

SikaReematLite-en-DK-(05-2020)-3-1.pdf